





Worldwide Leader in Steaming Equipment Since 1940

NEW Check Valve System



All Jiffy Steamers, with an external water supply, have a new no-spill check valve system. This update allows the user to easily invert a full water bottle onto the steamer base without spilling water. Once the water reservoir is cradled on the steamer, a post inside the water cup activates the check valve, which allows water to flow into the steam chamber. We have the ability to retrofit your older model Jiffy Steamer with this feature as well.



Jiffy Steamer Company, LLC

4462 Ken-Tenn Highway (38261) Post Office Box 869 Union City, Tennessee 38281-0869 United States of America

Phone: 1-731-885-6690 Fax: 1-731-885-6692 Web: www.jiffysteamer.com E-mail: jsinfo@jiffysteamer.com