


# Mounting Your Jiffy® Steamer Steamboard



Worldwide Leader in Steaming Equipment Since 1940


Our three suggested options. . .



Option A

## DOOR BRACKET


Use the over-the-door bracket for convenience and versatility. The Jiffy® Steamer Steamboard can be left hanging or taken down and moved to another site or stored.



Option B

## BASEBOARD STAND

Attach your Jiffy® Steamer Steamboard to the baseboard along your wall using the leg bracket kit. By securing the legs to the Steamboard with the enclosed "L" bolts, the top of the board will rest against the wall.



Option C

## WALL ATTACHMENT

Fasten the Jiffy® Steamer Steamboard to your wall for a permanent position. Use the two pre-drilled holes at the top of the board for an easy installation.

## Parts List for Steamboard

Item	Quantity
24" x 48" Steamboard	1
Over-the-door bracket for steamboard	1
Spring-loaded clothes clamp	1
Stamped metal plate for clothes clamp	1
Plastic bar for clothes clamp	1
#6 x 1/2" Phillips pan screw for metal plate	4
#6 x 1/2" Phillips pan screw for clothes clamp assembly	2
Anti-slip o-ring for clothes clamp	4
Plastic bumper for steamboard	5
Screw for plastic bumper	5
#8 x 2" Phillips screw to mount board to the wall	2
Angled bracket leg	2
"L" bolt for bracket leg	2
Lock washer for "L" bolt	2
Wing nut for "L" bolt	2
#6 x 1 1/4" screw to attach leg to baseboard	4



Comments? Questions?  
Jiffy® Steamer Company Hotline  
1-800-J2-Jiffy  
(1-800-525-4339)

Jiffy Steamer Company, LLC

4462 Ken-Tenn Highway (38261) Post Office Box 869 Union City, Tennessee 38281-0869 United States of America  
Phone: 1-731-885-6690 Fax: 1-731-885-6692 Web: www.jiffysteamer.com E-mail: jsinfo@jiffysteamer.com